Stock Service Entrance Switchboards

SWITCHBOARDS 13

Description	Catalog Number	
Underground Pull Section or Full Height Section For Load Wiring — Discount Schedule SWBD		
14.5" Deep 90" High 14" Wide (12" opening) — indoor 15" Wide (12" opening) — outdoor	PUG14 [®] WPUG14 [®]	
26" Wide (24" opening) — indoor 27" Wide (24" opening) — outdoor	PUG26 WPUG26	
10" Wide (load wiring)	PLW10	

Lug Landing Kits — Discount Schedule SWBD (Requires Catalog Number PUG26 or WPUG26)

400A	1-Phase, 3-Wire or 3-Phase, 4-Wire	PLL44 ^①
600A	1-Phase, 3-Wire or 3-Phase, 4-Wire	PLL46 ^①
800A	1-Phase, 3-Wire or 3-Phase, 4-Wire	PLL48 ^①

Optional Meter Sockets and Doors — Discount Schedule SWBD

Meter Compartment Door (32" Wide x 15" High for "S" base socket with test block cutout (order necessary meter base from items below)	PSP32
Meter Compartment Door (32" Wide x 30" High) for 2 "S" base meters with mounting provisions for test block and printing demand meter (order meter base from table below) Left Hand Hinge or Right Hand Hinge	PSDP32
Blank Meter Compartment Door (32" Wide x 15" High)	PBP32
5 Clip Meter Socket with ring	PMS5
6 Clip Meter Socket with ring	PMS6
8 Clip Meter Socket with ring	PMS8
13 Clip Meter Socket with ring	PMS13
15 Clip Meter Socket with ring	PMS15

Equipment Ground Bus — Discount Schedule SWBD

	PEGB42

For inches / millimeters conversion, see conversion table in Application Data section. = Warehouse Stock

• A suffix. New 'Series A' design

 A PUG26 or WPUG26 Underground pull section is required when using these lug landing kits.
Non- EUSERC compliant