

SIEMENS

Siemens Industry Inc.
Norcross Ga. 30092 U.S.A.

Item: MSJ6 Mounting Kit
For Use with: I-T-E® JXD, LXD,
JM and LM Circuit Breakers, Molded
Case Switches, & Motor Circuit
Interrupters. (Types listed below.)

Pages: 1 of 1

Pc. No. 66456A01



Installation Instructions



DANGER

HAZARDOUS VOLTAGE

**Will cause death or serious injury.
Turn power off supplying device
before installing kit.**



SAFETY INSTRUCTIONS

NOTE: This kit contains bolts, washers & nuts to install the following types: I-T-E® Circuit Breakers. JD Frame Types JXD2(-A), JXD6(-A), HJXD6(-A), HHJXD6, and CJD6(-A). LD Frame Types LXD6(-A), HLXD6(-A), HHLXD6, and CLD6(-A). ETI Motor Circuit Interrupters Types JXD6(-A)ETI, CJD6(-A)ETI, LXD6(-A)ETI, CLD6(-A)ETI. Solid State Molded Case Circuit Breaker Sentron Series III: JD Frame Types SJD6(-A), SHJD6(-A), SCJD6(-A), JM Frame Types JM6 and JMK Circuit Breakers, LM Frame Types LM6 and LMK Circuit Breakers & JDFP(-A); LD Frame Types SLD6(-A), SHLD6(-A), SCLD6(-A), & LDFP(-A).

1. Turn power off supplying device before installing kit.
2. Remove (Line and Load) line shields. (Illustration shows line shields removed)
3. Assemble bolts **(A)** through circuit breaker as shown. Tighten bolts using reps nuts **(B)** as required. For SCJD6, SCLD6, CJD6(ETI), and CLD6(ETI) breakers 6 bolts (2 kits) are required.
4. Replace (Line and Load) line shield.

