

SIEMENS

Siemens Energy & Automation, Inc.
Bellefontaine, Ohio 43311 U.S.A.

© Siemens Energy & Automation, Inc. 1987

Item: ED2-HPL Padlocking Device
For Use with: E, ED & EF Frame
Circuit Breakers & Molded Case
Switches (See Types Below)

Page 1 of 1

Pc. No. 73817A02

Installation Instructions



⚠ DANGER

Hazardous Voltage
Will cause death or serious injury.

Turn power off supplying device
before installing.



SAFETY INSTRUCTIONS

Breaker Types: E2(A), (H)E4(-A), (H)E6(-A)(ETI), CLE(-A)(ETI), ED2(Y), (H)ED4, (H)ED6(ETI), CED6(ETI), EFF, EFC

1. Turn power off supplying breaker before installing kit.
2. Turn breaker handle to off position before installing padlocking device.
3. Install device by slipping over breaker handle as shown and place tab **A** into slot **B**, push tab **C** into slot **D**, and then tighten screws **E**.
4. Remove tag and wire from device.
5. Place label "O" "OFF" positon in this area and/or on panelboard if installed.
6. Same as #5, except in "I" "ON" positon.

