

FAUX PLI À 2"

PATRON DE DÉCOUPAGE
POUR BOÎTE DE SORTIE
54151-LD / 54171-LD

**CE CÔTÉ FACE AU
MUR OU PLAFOND**

IBERVILLE[®]md

Thomas & Betts

Membre du Groupe ABB • A Member of the ABB Group

**THIS SIDE FACING
WALL OR CEILING**

CUT OUT TEMPLATE FOR
54151-LD / 54171-LD
OUTLET BOX

INSTRUCTIONS

Découper l'ouverture à l'intérieur de la ligne

1. Tracer et découper du côté intérieur à la ligne l'ouverture dans le mur.
2. Tirer le(s) câble(s) hors de l'ouverture et dénuder approx. 10" de gaine isolante.
3. Insérer le(s) câble(s) dénudé(s) dans la(les) débouchure(s) et serrer la bride.
4. Desserrer les vis de montage à levier à l'épaisseur désirée.
5. Insérer la boîte dans son ouverture.
6. Serrer les vis de montage en s'assurant que les leviers à bascule soient levés.

Cut opening inside of traced line

1. Trace this side of pattern and cut the opening in wall on the inside of the traced line.
2. Fish cable(s) to opening and strip approx. 10" of insulation.
3. Pull cable(s) through pryout(s) and tighten cable clamp(s).
4. Loosen mounting screws to compensate for wall thickness.
5. Insert box into opening
6. Tighten mounting screws while ensuring swing arms are in an upright position.

CTA01278 A

**CE CÔTÉ POUR TRACER
THIS SIDE FOR
TRACING**