

Sta-Kon®

Thomas & Betts



WIRE JOINT - CAT. NO. PT80 FOR SOLID OR STRANDED WIRES

- | | |
|---------------------------------|--------------------------|
| 2 #16 sol | 4 #10 sol or str |
| 12 #16 sol or str | 1 #10 sol with 2 #14 str |
| 2 #16 sol or str with 2 #10 sol | 1 #10 sol with 3 #14 str |
| 1 #14 sol with 2 #14 str | 2 #8 sol or str |
| 9 #14 sol or str | |

INSTALLATION INSTRUCTIONS



1. Strip insulation from conductors.

2. Twist stripped wires together.



3. Insert wires in metal connector.

4. Crimp with tool WT161M.



5. Trim off excess wire.

Thomas & Betts Corporation - Memphis, Tennessee 38125 - www.t&b.com
Made in U.S.A. Printed in U.S.A. TA01210 B