

Vapour Barrier Extender for Remodel IC Applications



- Only available from Liteline
- Required by Code
- Only way to seal vapour barrier for Remodel Potlights
- Easy install, fits through ceiling cut hole and expands above the ceiling
- Includes peel and stick collar to stick directly to vapour barrier – NO TUCK TAPE REQUIRED
- Works with 3.5" and 4" Potlights



Housing not included

Ordering Guide

Part #	Description	UPC	Master Qty.
VBE-2	Vapor barrier extender for use with RF3.5, 4in Remodel ICAT	771250971388	50