



Serial Communications

The serial communications expansion module provides a Modbus Master port for a Genius NIU remote I/O drop. The serial port can be used to interface with a wide range of Modbus slave devices such as controllers, VFDs, bar code readers, marques and much more. The data is transferred to and from the NIU over the Genius LAN and is compatible with any controller that supports Genius Global Data.

IC200CMM020

Product Name	Modbus Master Module, 1 RS-485 port. Requires IC200CHS006 Communications Carrier.
Lifecycle Status	Active
Module Type	Modbus Master
NIU Type Supported	Genius and PROFINET Slave
Number of Serial Communications Modules	Up to 2 per Genius NIU I/O Station
Number of RTU slaves per Serial Communications Module	1 to 247
Serial Port Type	RS-485. 15-pin subminiature 'D' connector. For RS-232 communications, an RS-485 to RS-232 adapter such as IC690ACC901 can be used. Adapter IC690ACC901 can be installed with its right-angle cable hanging down. RS-485 supports both 2-wire and 4-wire electrical interfaces
Baud Rate Supported	1200, 2400, 4800, 9600, and 19200, and half or full duplex operation
COMMREQ command memory (%AQ) required in the GENERIC_COMM module hardware configuration	Depends on individual COMMREQ content. Minimum: 22 words Maximum: 64 words
RTU Master Commands	65520, Initialize RTU Master Port 8000, Clear RTU Master Diag. Status 8001, Read RTU Master Diag. Status 8002, Send RTU Read/Force/Preset Query 8003, Send RTU Diagnostic Query
Power Consumption	460 mA maximum from 5 V output, 5 mA from +3.3 V output
Dimensions (W x H x D)	110mm (4.3in) x 66.8mm (2.63in) x 50mm (1.956 in), not including the height of the carrier or the mating connectors

Accessories

IC200ACC001	Replacement Battery for VersaMax CPUs	Active
IC200ACC003	EZ Program Store, CPU RS-485 Port Update Device	Active
IC200ACC201	Expansion Terminator QTY 1	Active
IC200ACC202	Expansion Terminator QTY 2	Active
IC690ACC905	Encapsulated Thermistor Kit QTY 2	Active
IC200ACC301	I/O Filler Module	Active
IC200ACC302	I/O Input Simulator	Active
IC200ACC303	I/O Shorting Bar QTY 2	Active
IC200ACC304	Cable Connector Kit, QTY 2, for connector base (IC200CHS003) I/O Base (IC200CHS011, CHS012, CHS014, CHS015 and CHS1xx bases)	Active
IC200ACC313	DIN-rail clips (Qty 2) to secure modules on DIN-rail	Active
IC200TBM001	I/O Auxiliary Terminal Strip, 18 Internally Bussed, Barrier Style	Active
IC200TBM002	I/O Auxiliary Terminal Strip, 18 Internally Bussed, Box Style	Active
IC200TBM005	I/O Auxiliary Terminal Strip, 18 Internally Bussed, Spring Clamp Style	Active

Cables for Connector Type Carrier

IC200CBL105	Cable, I/O Non-Shielded, 2 Connectors, 0.5M used with IC200CHS003 and IC200CHS011, 012, 015.	Active
IC200CBL110	Cable, I/O Non-Shielded, 2 Connectors, 1.0M used with IC200CHS003 and IC200CHS011, 012, 015.	Active
IC200CBL120	Cable, I/O Non-Shielded, 2 Connectors, 2.0M used with IC200CHS003 and IC200CHS011, 012, 015.	Active
IC200CBL230	Cable, I/O Non-Shielded, 1 Connector, 3.0M used with IC200CHS003 and IC200CHS011, 012, 015.	Active

Cables to Connect Rack to Rack Expansion

IC200CBL600	Rack Expansion Cable, Shielded, Single Ended, 1M to One Expansion Receiver Module (IC200ERM00x)	Active
IC200CBL601	Rack Expansion Cable, Shielded, 2 Connectors, 1M. Supports Multidrop to Multiple Expansion Receiver Modules (IC200ERM00x)	Active
IC200CBL602	Rack Expansion Cable, Shielded, 2 Connectors, 2M. Supports Multidrop to Multiple Expansion Receiver Modules (IC200ERM00x)	Active
IC200ACC304	Cable Connector Kit, QTY 2, for connector base (IC200CHS003) I/O Base (IC200CHS011, CHS012, CHS014, CHS015 and CHS1xx bases)	Active

Starter Kits

IC200PKG001	PLC Starter Kit CPU001	Contains CPU001, PWR101, MDD845, CHS002, ACC302, CBL001, GFK-1503, GFK-1504, 641VPS300 (Infolink included), coffee mug, and plastic carry case. Does not include 24 VDC power supply for inputs.	Active
IC200PKG010	PLC Starter Kit CPUE05	Contains CPUE05, PWR101, MDD845, CHS002, ACC302, CBL001, GFK-1503, GFK-1504, Machine Edition (Infolink included), coffee mug, and plastic carry case. Does not include 24 VDC power supply for inputs.	Active
IC200PKG101	I/O Starter Kit GENIUS	Contains GBI001, PWR101, MDD845, CHS002, ACC302, CBL001, GFK-1535, GFK-1504, 690CDR002 (Infolink), coffee mug, and plastic carry case. Does not include 24 VDC power supply for inputs.	Active
IC200PKG102	I/O Starter Kit PROFIBUS-DP	Contains PBI001, PWR101, MDD845, CHS002, ACC302, CBL001, GFK-1534, GFK-1504, 690CDR002 (Infolink), coffee mug, and plastic carry case. Does not include 24 VDC power supply for inputs.	Active
IC200PKG103	I/O Starter Kit DeviceNet	Contains DBI001, PWR101, MDD845, CHS002, ACC302, CBL001, GFK-1533, GFK-1504, 690CDR002 (Infolink), coffee mug, and plastic carry case. Does not include 24 VDC power supply for inputs.	Active
IC200PKG104	I/O Starter Kit Ethernet	Contains EBI001, PWR101, MDD845, CHS002, ACC302, CBL001, GFK-1534, GFK-1504, Machine Edition (Infolink), coffee mug, and plastic carry case. Does not include 24 VDC power supply for inputs.	Active