

Machine & Operational

B

CAUTION
OVERHEAD
EQUIPMENT 

FG - 7 x 17 - 69418

CAUTION
OVERHEAD
WORK

FG - 10 x 14 - 70470
AL - 7 x 10 - 42446
AL - 10 x 14 - 42447
PL - 7 x 10 - 22923
PL - 10 x 14 - 22924
SS - 7 x 10 - 85870
SS - 10 x 14 - 85871

CAUTION
ROBOT OPERATING AREA
DO NOT ENTER
AUTHORIZED PERSONS ONLY

FG - 14 x 20 - 73472
AL - 7 x 10 - 40633
AL - 10 x 14 - 40634
PL - 7 x 10 - 22069
PL - 10 x 14 - 22070
SS - 7 x 10 - 84026
SS - 10 x 14 - 84027

CAUTION
STAND CLEAR
OF DOOR

FG - 10 x 14 - 70532
AL - 7 x 10 - 42450
AL - 10 x 14 - 42451
PL - 7 x 10 - 22519
PL - 10 x 14 - 22520
SS - 7 x 10 - 84710
SS - 10 x 14 - 84711

CAUTION
STEP DOWN

FG - 7 x 10 - 74350
AL - 7 x 10 - 42452
AL - 10 x 14 - 42453
PL - 7 x 10 - 22929
PL - 10 x 14 - 22930
SS - 7 x 10 - 85886
SS - 10 x 14 - 85887

CAUTION
THIS MACHINE
MUST BE
LOCKED OUT
PRIOR TO
SERVICING

FG - 10 x 7 - 65517
FG - 14 x 10 - 65516
AL - 10 x 7 - 42454
AL - 14 x 10 - 42455
PL - 10 x 7 - 22931
PL - 14 x 10 - 22932
SS - 5 x 3½ - 85890
SS - 7 x 5 - 85891
SS - 10 x 7 - 85892
SS - 14 x 10 - 85893

CAUTION
THIS MACHINE
STARTS BY
REMOTE CONTROL

FG - 10 x 14 - 74377
AL - 7 x 10 - 42456
AL - 10 x 14 - 42457
PL - 7 x 10 - 22933
PL - 10 x 14 - 22934
SS - 7 x 10 - 85896
SS - 10 x 14 - 85897

CAUTION
THIS MOTOR
STARTS BY
REMOTE CONTROL

FG - 10 x 14 - 69531
AL - 7 x 10 - 42458
AL - 10 x 14 - 42459
PL - 7 x 10 - 22935
PL - 10 x 14 - 22936
SS - 7 x 10 - 85898
SS - 10 x 14 - 85899

CAUTION
TURN MACHINE
OFF
WHEN NOT IN USE

FG - 10 x 14 - 70563
AL - 7 x 10 - 42460
AL - 10 x 14 - 42461
PL - 7 x 10 - 22937
PL - 10 x 14 - 22938
SS - 7 x 10 - 85900
SS - 10 x 14 - 85901

CAUTION
USE FUSE PULLER TO
CHANGE FUSES

SS - 3½ x 5 - 85902

CAUTION
WATCH FOR
LIFT TRUCKS 

FG - 7 x 17 - 70575

CAUTION
WATCH FOR
LIFT TRUCKS 

AL - 10 x 14 - 43483
PL - 10 x 14 - 25906

CAUTION
WATCH OUT
FOR FORK LIFT
TRUCKS 

FG - 7 x 17 - 70577

CAUTION
WATCH OUT
FOR FORK TRUCK
OPERATING IN AREA

FG - 14 x 20 - 74442
AL - 7 x 10 - 42462
AL - 10 x 14 - 42463
PL - 7 x 10 - 22939
PL - 10 x 14 - 22940
SS - 7 x 10 - 85903
SS - 10 x 14 - 85904

CAUTION
WATCH
OVERHEAD CLEARANCE

FG - 10 x 14 - 70579
AL - 7 x 10 - 42464
AL - 10 x 14 - 42465
PL - 7 x 10 - 22941
PL - 10 x 14 - 22942
SS - 7 x 10 - 85905
SS - 10 x 14 - 85906

CAUTION
WATCH YOUR
FINGERS AND
YOUR HANDS 

FG - 7 x 17 - 70580

CAUTION
WATCH YOUR
FINGERS AND
YOUR HANDS 

AL - 10 x 14 - 43484
PL - 10 x 14 - 25907

CAUTION
WEAR GOGGLES
OR FACE SHIELD
WHILE OPERATING THIS MACHINE

FG - 10 x 14 - 74495
AL - 7 x 10 - 41164
AL - 10 x 14 - 41165
PL - 7 x 10 - 22600
PL - 10 x 14 - 22601
SS - 7 x 10 - 84999
SS - 10 x 14 - 85000

CAUTION
WEAR GOGGLES
WHEN USING
THIS MACHINE 

FG - 7 x 17 - 70587

CAUTION
WHEN THROWING
SWITCH
USE LEFT HAND
AND
TURN FACE AWAY

FG - 10 x 7 - 65576
FG - 14 x 10 - 65575
AL - 10 x 7 - 42466
AL - 14 x 10 - 42467
PL - 10 x 7 - 22943
PL - 14 x 10 - 22944
SS - 5 x 3½ - 85911
SS - 7 x 5 - 85912
SS - 10 x 7 - 85913
SS - 14 x 10 - 85914

DANGER
AUTOMATIC START
EQUIPMENT

FG - 10 x 14 - 73009
AL - 7 x 10 - 42468
AL - 10 x 14 - 42469
PL - 7 x 10 - 22945
PL - 10 x 14 - 22946
SS - 7 x 10 - 85919
SS - 10 x 14 - 85920

DANGER
CLOSE
CLEARANCE

FG - 10 x 14 - 69046
AL - 7 x 10 - 42470
AL - 10 x 14 - 42471
PL - 7 x 10 - 22947
PL - 10 x 14 - 22948
SS - 7 x 10 - 85921
SS - 10 x 14 - 85922

DANGER
CRANE
OVERHEAD

FG - 14 x 20 - 73052
AL - 7 x 10 - 42472
AL - 10 x 14 - 42473
PL - 7 x 10 - 22949
PL - 10 x 14 - 22950
SS - 7 x 10 - 85923
SS - 10 x 14 - 85924

DANGER
CRANE
SWING

SS - 7 x 10 - 85925
SS - 10 x 14 - 85926

DANGER
CRANE WORKING
OVERHEAD

FG - 10 x 14 - 73058
AL - 7 x 10 - 42474
AL - 10 x 14 - 42475
PL - 7 x 10 - 22951
PL - 10 x 14 - 22952
SS - 7 x 10 - 85927
SS - 10 x 14 - 85928

DANGER
CROSSING OR STANDING
ON CONVEYOR IS
FORBIDDEN

FG - 10 x 14 - 69075
AL - 7 x 10 - 43191
AL - 10 x 14 - 43192
PL - 7 x 10 - 25614
PL - 10 x 14 - 25615
SS - 7 x 10 - 85101
SS - 10 x 14 - 85102

DANGER
DO NOT LOOK AT
ELECTRIC ARC
IT WILL HURT YOUR EYES

FG - 10 x 14 - 69121
AL - 7 x 10 - 41170
AL - 10 x 14 - 41171
PL - 7 x 10 - 22606
PL - 10 x 14 - 22607
SS - 7 x 10 - 85007
SS - 10 x 14 - 85008

DANGER
DO NOT OPERATE
CONTROLS WHILE THIS
SIGN IS IN PLACE

FG - 10 x 14 - 69127
AL - 7 x 10 - 42476
AL - 10 x 14 - 42477
PL - 7 x 10 - 22953
PL - 10 x 14 - 22954
SS - 7 x 10 - 85941
SS - 10 x 14 - 85942

DANGER
DO NOT OPERATE
MEN WORKING
ON REPAIRS

FG - 7 x 10 - 73086
AL - 7 x 10 - 42478
AL - 10 x 14 - 42479
PL - 7 x 10 - 22955
PL - 10 x 14 - 22956
SS - 7 x 10 - 85943
SS - 10 x 14 - 85944

DANGER
DO NOT OPERATE THIS
MACHINE WITHOUT
EYE PROTECTION 

FG - 7 x 17 - 70277

DANGER
DO NOT OPERATE
WITHOUT GUARDS
IN PLACE 

FG - 7 x 17 - 69131

DANGER
DO NOT
STAND HERE

FG - 10 x 14 - 69144
AL - 7 x 10 - 42480
AL - 10 x 14 - 42481
PL - 7 x 10 - 22957
PL - 10 x 14 - 22958
SS - 7 x 10 - 85949
SS - 10 x 14 - 85950

DANGER
DO NOT START
ENGINE

FG - 7 x 10 - 73452
AL - 7 x 10 - 42482
AL - 10 x 14 - 42483
PL - 7 x 10 - 22959
PL - 10 x 14 - 22960
SS - 7 x 10 - 85953
SS - 10 x 14 - 85954

DANGER
DO NOT START
MACHINE BEING
REPAIRED

FG - 10 x 14 - 69148
AL - 7 x 10 - 42484
AL - 10 x 14 - 42485
PL - 7 x 10 - 22961
PL - 10 x 14 - 22962
SS - 7 x 10 - 85957
SS - 10 x 14 - 85958

DANGER
DO NOT START
THIS MACHINE

FG - 10 x 14 - 74111
AL - 7 x 10 - 42486
AL - 10 x 14 - 42487
PL - 7 x 10 - 22963
PL - 10 x 14 - 22964
SS - 7 x 10 - 85959
SS - 10 x 14 - 85960

DANGER
DO NOT USE

AL - 7 x 10 - 43497

DANGER
DO NOT WATCH
ARC WELDER AT WORK
THE LIGHT WILL BLIND YOU

FG - 10 x 14 - 69170
AL - 7 x 10 - 42490
AL - 10 x 14 - 42491
PL - 7 x 10 - 22967
PL - 10 x 14 - 22968
SS - 7 x 10 - 85973
SS - 10 x 14 - 85974

DANGER
DO NOT WATCH
THE ARC

FG - 10 x 14 - 74132
AL - 7 x 10 - 42488
AL - 10 x 14 - 42489
PL - 7 x 10 - 22965
PL - 10 x 14 - 22966
SS - 7 x 10 - 85971
SS - 10 x 14 - 85972

DANGER
DON'T CLEAN OR
REPAIR MACHINERY
WHILE IN MOTION

FG - 7 x 10 - 70290
AL - 7 x 10 - 42492
AL - 10 x 14 - 42493
PL - 7 x 10 - 22969
PL - 10 x 14 - 22970
SS - 7 x 10 - 85975
SS - 10 x 14 - 85976