

For lamps, see page 9/108.

Safety function in accordance with IEC 60 947-5-1-3 and DIN VDE 0660, Pt. 200.

When a contact block is fitted to the centre position of a holder, the appropriate extra parts (thrust cap for pushbutton, thrust pad for rotary)

drive) must be fitted to the actuator plunger (see page 9/108).

2) Contact block <u>only</u> suitable for joystick switches.

3) Not suitable for EMERG pushbutton with positive accordance with EN 41 3SB10 00–1MC00.

9/96

Only supplied in packings