
Ε

Mushroom heads



Knobs and levers

Description	Cat. no.	Ref. no.	Cat. no.	Ref. no.
		see bottom		see bottom
	Plast	ic	Plast	ic
Knob for selector switches	P9ACMN●		P9ACMN●	
Lever for selector switches	P9ARMV●			

Lenses

	Descriptio	n	Cat. no.	Ref. no. see bottom	Cat. no.	Ref. no. see bottom
			Plast	ic	Plast	tic
			0			
	Pilot lights	diffused version	P9ARGLD●		P9ASGLD●	
		refracted version	P9ARGLR●			
		glass version	P9ARGLV●			
	Illuminated push-buttons	diffused version	P9ARGPD●		P9ASGPD●	
	Illuminated mushroom head push-b.	momentary Ø 40 mm	P9ARGP4●			
		⊿ 30 mm				
All second	-	push-pull Ø 40 mm	P9ACGP4●			
	Illuminated selector switches	knob	P9ACGSL●		P9ACGSL●	
		lever	P9ARGSA●			

Rubber protective caps (IP66)

Description		Cat. no.	Ref. no. see bottom	Cat. no.	Ref. no. see botton
		Plastic Plast		tic	
Standard flush push-buttons	coloured (nitrilic rubber)	080CP●		P9ASCG●	
·	clear (silicon rubber)	080CPT	170198	P9ASCGT	170790
Raised push buttons	clear (silicon rubber)	P9ARCST	187490	P9ASCST	187791

The catalogue numbers ${\bf in\ bold}$ are available from stock.

Colours	black	red	green	yellow	orange		white	clear
Mushroom heads	N	R	V	G	-	L	-	-
Knobs/lever •	N	R	V	G	-	L	-	-
Lenses	_	R	V	G	Α	L	В	I
Protective caps •	N	R	V	G	-		-	-

For reference numbers see chapter X, pg. X.10

