

Accessories

| | | |
|-------------|--|--------|
| IC200ACC001 | Replacement Battery for VersaMax CPUs | Active |
| IC200ACC003 | EZ Program Store, CPU RS-485 Port Update Device | Active |
| IC200ACC201 | Expansion Terminator QTY 1 | Active |
| IC200ACC202 | Expansion Terminator QTY 2 | Active |
| IC690ACC905 | Encapsulated Thermistor Kit QTY 2 | Active |
| IC200ACC301 | I/O Filler Module | Active |
| IC200ACC302 | I/O Input Simulator | Active |
| IC200ACC303 | I/O Shorting Bar QTY 2 | Active |
| IC200ACC304 | Cable Connector Kit, QTY 2, for connector base (IC200CHS003) I/O Base (IC200CHS011, CHS012, CHS014, CHS015 and CHS1xx bases) | Active |
| IC200ACC313 | DIN rail clips (Qty 2) to secure modules on DIN rail | Active |
| IC200TBM001 | I/O Auxiliary Terminal Strip, 18 Internally Bussed, Barrier Style | Active |
| IC200TBM002 | I/O Auxiliary Terminal Strip, 18 Internally Bussed, Box Style | Active |
| IC200TBM005 | I/O Auxiliary Terminal Strip, 18 Internally Bussed, Spring Clamp Style | Active |

Cables for Connector Type Carrier

| | | |
|-------------|--|--------|
| IC200CBL105 | Cable, I/O Non-Shielded, 2 Connectors. 0.5M used with IC200CHS003 and IC200CHS011, 012, 015. | Active |
| IC200CBL110 | Cable, I/O Non-Shielded, 2 Connectors, 1.0M used with IC200CHS003 and IC200CHS011, 012, 015. | Active |
| IC200CBL120 | Cable, I/O Non-Shielded, 2 Connectors, 2.0M used with IC200CHS003 and IC200CHS011, 012, 015. | Active |
| IC200CBL230 | Cable, I/O Non-Shielded, 1 Connector, 3.0M used with IC200CHS003 and IC200CHS011, 012, 015. | Active |

Cables to Connect Rack to Rack Expansion

| | | |
|-------------|--|--------|
| IC200CBL600 | Rack Expansion Cable, Shielded, Single Ended, 1M to One Expansion Receiver Module (IC200ERM00x) | Active |
| IC200CBL601 | Rack Expansion Cable, Shielded, 2 Connectors, 1M. Supports Multidrop to Multiple Expansion Receiver Modules (IC200ERM00x) | Active |
| IC200CBL602 | Rack Expansion Cable, Shielded, 2 Connectors, 2M. Supports Multidrop to Multiple Expansion Receiver Modules (IC200ERM00x) | Active |
| IC200ACC304 | Cable Connector Kit, QTY 2, for connector base (IC200CHS003) I/O Base (IC200CHS011, CHS012, CHS014, CHS015 and CHS1xx bases) | Active |

Starter Kits

| | | | |
|-------------|-----------------------------|--|--------|
| IC200PKG001 | PLC Starter Kit CPU001 | Contains CPU001, PWR101, MDD845, CHS002, ACC302, CBL001, GFK-1503, GFK-1504, 641VPS300 (Infolink included), coffee mug, and plastic carry case. Does not include 24 VDC power supply for inputs. | Active |
| IC200PKG010 | PLC Starter Kit CPUE05 | Contains CPUE05, PWR101, MDD845, CHS002, ACC302, CBL001, GFK-1503, GFK-1504, Machine Edition (Infolink included), coffee mug, and plastic carry case. Does not include 24 VDC power supply for inputs. | Active |
| IC200PKG101 | I/O Starter Kit GENIUS | Contains GBI001, PWR101, MDD845, CHS002, ACC302, CBL001, GFK-1535, GFK-1504, 690CDR002 (Infolink), coffee mug, and plastic carry case. Does not include 24 VDC power supply for inputs. | Active |
| IC200PKG102 | I/O Starter Kit Profibus-DP | Contains PBI001, PWR101, MDD845, CHS002, ACC302, CBL001, GFK-1534, GFK-1504, 690CDR002 (Infolink), coffee mug, and plastic carry case. Does not include 24 VDC power supply for inputs. | Active |
| IC200PKG103 | I/O Starter Kit DeviceNet | Contains DBI001, PWR101, MDD845, CHS002, ACC302, CBL001, GFK-1533, GFK-1504, 690CDR002 (Infolink), coffee mug, and plastic carry case. Does not include 24 VDC power supply for inputs. | Active |
| IC200PKG104 | I/O Starter Kit Ethernet | Contains EBI001, PWR101, MDD845, CHS002, ACC302, CBL001, GFK-1534, GFK-1504, Machine Edition (Infolink), coffee mug, and plastic carry case. Does not include 24 VDC power supply for inputs. | Active |