

Accessories

IC200ACC001	Replacement Battery for VersaMax CPUs	Active
IC200ACC003	EZ Program Store, CPU RS-485 Port Update Device	Active
IC200ACC201	Expansion Terminator QTY 1	Active
IC200ACC202	Expansion Terminator QTY 2	Active
IC690ACC905	Encapsulated Thermistor Kit QTY 2	Active
IC200ACC301	I/O Filler Module	Active
IC200ACC302	I/O Input Simulator	Active
IC200ACC303	I/O Shorting Bar QTY 2	Active
IC200ACC304	Cable Connector Kit, QTY 2, for connector base (IC200CHS003) I/O Base (IC200CHS011, CHS012, CHS014, CHS015 and CHS1xx bases)	Active
IC200ACC313	DIN-rail clips (Qty 2) to secure modules on DIN-rail	Active
IC200TBM001	I/O Auxiliary Terminal Strip, 18 Internally Bussed, Barrier Style	Active
IC200TBM002	I/O Auxiliary Terminal Strip, 18 Internally Bussed, Box Style	Active
IC200TBM005	I/O Auxiliary Terminal Strip, 18 Internally Bussed, Spring Clamp Style	Active

Cables for Connector Type Carrier

IC200CBL105	Cable, I/O Non-Shielded, 2 Connectors. 0.5M used with IC200CHS003 and IC200CHS011, 012, 015.	Active
IC200CBL110	Cable, I/O Non-Shielded, 2 Connectors, 1.0M used with IC200CHS003 and IC200CHS011, 012, 015.	Active
IC200CBL120	Cable, I/O Non-Shielded, 2 Connectors, 2.0M used with IC200CHS003 and IC200CHS011, 012, 015.	Active
IC200CBL230	Cable, I/O Non-Shielded, 1 Connector, 3.0M used with IC200CHS003 and IC200CHS011, 012, 015.	Active

Cables to Connect Rack to Rack Expansion

IC200CBL600	Rack Expansion Cable, Shielded, Single Ended, 1M to One Expansion Receiver Module (IC200ERM00x)	Active
IC200CBL601	Rack Expansion Cable, Shielded, 2 Connectors, 1M. Supports Multidrop to Multiple Expansion Receiver Modules (IC200ERM00x)	Active
IC200CBL602	Rack Expansion Cable, Shielded, 2 Connectors, 2M. Supports Multidrop to Multiple Expansion Receiver Modules (IC200ERM00x)	Active
IC200ACC304	Cable Connector Kit, QTY 2, for connector base (IC200CHS003) I/O Base (IC200CHS011, CHS012, CHS014, CHS015 and CHS1xx bases)	Active

Starter Kits

IC200PKG001	PLC Starter Kit CPU001	Contains CPU001, PWR101, MDD845, CHS002, ACC302, CBL001, GFK-1503, GFK-1504, 641VPS300 (Infolink included), coffee mug, and plastic carry case. Does not include 24 VDC power supply for inputs.	Active
IC200PKG010	PLC Starter Kit CPUE05	Contains CPUE05, PWR101, MDD845, CHS002, ACC302, CBL001, GFK-1503, GFK-1504, Machine Edition (Infolink included), coffee mug, and plastic carry case. Does not include 24 VDC power supply for inputs.	Active
IC200PKG101	I/O Starter Kit GENIUS	Contains GBI001, PWR101, MDD845, CHS002, ACC302, CBL001, GFK-1535, GFK-1504, 690CDR002 (Infolink), coffee mug, and plastic carry case. Does not include 24 VDC power supply for inputs.	Active
IC200PKG102	I/O Starter Kit PROFIBUS-DP	Contains PBI001, PWR101, MDD845, CHS002, ACC302, CBL001, GFK-1534, GFK-1504, 690CDR002 (Infolink), coffee mug, and plastic carry case. Does not include 24 VDC power supply for inputs.	Active
IC200PKG103	I/O Starter Kit DeviceNet	Contains DBI001, PWR101, MDD845, CHS002, ACC302, CBL001, GFK-1533, GFK-1504, 690CDR002 (Infolink), coffee mug, and plastic carry case. Does not include 24 VDC power supply for inputs.	Active
IC200PKG104	I/O Starter Kit Ethernet	Contains EBI001, PWR101, MDD845, CHS002, ACC302, CBL001, GFK-1534, GFK-1504, Machine Edition (Infolink), coffee mug, and plastic carry case. Does not include 24 VDC power supply for inputs.	Active