

Accessories

IC690ACC901	Miniconverter Kit with cable (RS-232 to RS-485)	Active
IC690CDR002	User Manuals, InfoLink CD-ROM Documentation, Single-user License	Active
IC697ACC700	Terminal Block, 40 Contacts (qty 6)	Mature
IC697ACC701	Replacement Battery for CPU and PCM (qty 2)	Mature
IC697ACC702	I/O Bus Terminator Plug	Mature
IC697ACC715	VME Option Kit, J2 Backplane Mounting	Mature
IC697ACC720	Blank Slot Filler (qty 6)	Mature
IC697ACC721	Rack Fan Assembly, 120VAC	Active
IC697ACC722	VME Backplane Connector, Interrupt Jumper (qty 6)	Mature
IC697ACC723	Clear Plastic Doors (qty 6)	Mature
IC697ACC724	Rack Fan Assembly, 240VAC	Active
IC697ACC726	Top PWA Cover, CPU-style (qty 6)	Mature
IC697ACC727	Top and Bottom PWA Cover, GBC (qty 2)	Mature
IC697ACC728	Top and Bottom PWA Cover, BTM/BTR (qty 2)	Mature
IC697ACC729	Top and Bottom PWA Cover, I/O Link (qty 2)	Mature
IC697ACC730	Spare Slot Terminal Strip Retainer	Mature
IC697ACC732	Top PWA Cover, CPU77x and CPU78x (qty 2)	Mature
IC697ACC736	Cable Shield Clamping Assembly	Active
IC697ACC744	Rack Fan Assembly, 24VDC	Active
IC697MLX000	Series 90-70 Labels Kit	Active

I/O Cables

IC600WD002	I/O Expansion Cable, 2 feet (0.6 meters)	Mature
IC600WD005	I/O Expansion Cable, 5 feet (1.5 meters)	Mature
IC600WD010	I/O Expansion Cable, 10 feet (3.0 meters)	Mature
IC600WD025	I/O Expansion Cable, 25 feet (7.5 meters)	Mature
IC600WD050	I/O Expansion Cable, 50 feet (15 meters)	Mature
IC690CBL701	Cables - PCM to IC640 or PC-XT Computer, 10 feet (3 meters)	Active
IC690CBL702	Cables - PCM to PC-AT Computer, 10 feet (3 meters)	Mature
IC690CBL705	Cables - PCM to IC642 or PS/2 Computer, 10 feet (3 meters)	Mature
IC697CBL709	Cable, MAP Controller to Broadband Modem	Mature
IC697CBL811	Cable, RCM Communications (10 feet) I/O Expansion Cable	Mature
IC697CBL826	Cable, RCM Communications (25 feet) I/O Expansion Cable	Mature