


System Features and Benefits

- Up to four sources per multi-source system
- Up to eight zones per multi-source system, with ability to expand
- Whole house control via universal remote and keypad
- · High performance and standard systems
- Up to two local source inputs per keypad
- Flush mount inputs in single and triple source versions
- · Classic design enhances any decor
- Efficient installation via Cat 5 wiring

COLORS



RELATED PRODUCTS



F7417-XX lyriQ Local Source Input



AU7394-XX lyriQ Keypad




AU1000-XX lyriQ High-Performance Keypad



AU7400-XX IyriQ Single Source, 4-Zone Kit

WIRING DIAGRAM



INSTALLATION AT-A-GLANCE lyriQ SINGLE-SOURCE AUDIO SYSTEM

- Run a single Cat 5 cable and speaker wire to each location where a keypad will be installed.
- Install each keypad in a standard single gang box and connect the Cat 5 cable and a pair of speakers to the keypad.
- 3. Install the single source distribution module in the On-Q enclosure and connect it to the keypads and source input.
- 4. Run a Cat 5 cable from the module to the location where the source input will be installed.
- 5. Install the input in a standard single-gang box and connect the Cat 5.
- 6. Connect the audio source to the source input.