









# Load Feeders and Motor Starters for Use in the Control Cabinet

## SIRIUS 3RA6 compact starters

Accessories

## Selection and ordering data

Version	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
<b>Accessories specially for 3RA6 compact starters</b>						
		<b>Control kit</b> For mechanical actuation of the compact starter		1	1 unit	42F
3RA6950-0A	A	<b>3RA6950-0A</b>				
		<b>Adapters for screw fixing the compact starter</b> (set including push-in lugs) Direct-on-line starters require one set, reversing starters two sets.		1	1 unit	42F
3RA6940-0A	A	<b>3RA6940-0A</b>				
		<b>Auxiliary switch blocks for compact starters</b> • 2 NO • 2 NC • 1 NO + 1 NC (these auxiliary contacts are positively driven.)				
3RA6911-1A	A	<b>3RA6911-1A</b>		1	1 unit	42F
		<b>Main circuit terminals</b> (input and output sides)		1	1 unit	42F
3RA6920-1A	A	<b>3RA6920-1A</b>				
		<b>Control circuit terminals</b> • For 3RA61 • For 3RA62		1	1 unit	42F
3RA6920-1B	A	<b>3RA6920-1B</b>		1	1 unit	42F
		<b>Auxiliary switch block for compact starters</b> • 2 NO • 2 NC • 1 NO + 1 NC (these auxiliary contacts are positively driven.)				
3RA6911-2A	A	<b>3RA6911-2A</b>		1	1 unit	42F
		<b>Main circuit terminals</b> (input and output sides)		1	1 unit	42F
3RA6920-2A	A	<b>3RA6920-2A</b>				
		<b>Control circuit terminals</b> • For 3RA61 • For 3RA62		1	1 unit	42F
3RA6920-2B	A	<b>3RA6920-2B</b>		1	1 unit	42F
	A	<b>3RA6920-2C</b>		1	1 unit	42F