
## **Microlectric**°

## Meter Sockets



LEFT-HAND ENTRY	<b>RIGHT-HAND ENTRY</b>						
BS42-V	BS42-VH	2 position		26-1/4	5-5/16	45	20.4
BS43-V	BS43-VH	3 position		35		59	26.8
BS44-V	BS44-VH	4 position	23-3/8	43-3/4		73	33.1
BS45-V	BS45-VH	5 position		52-1/2		87	39.5
BS46-V	BS46-VH	6 position		61-1/4		101	45.9





D29