

Meter Sockets

			Service Mast	S			
			Guy Kits for 2-1/2 ir	n. Masts	• • • • • • • •		•••
				MM914	Opena	Provide and a second	
				MM95	516		
	Qty.	Consists of	Description	MM95	516		
			Description	MM95	516	Constant of the second s	
	1	MM380	Description Mast Guy Attachment	MM95	516	Constant of the second s	
		MM380 GT516	Description Mast Guy Attachment Guy Thimbles	MM95	516		
/4 in. Guy Kit	1	MM380 GT516 GE14	Description Mast Guy Attachment Guy Thimbles Guy End	MM95	516		
	1 2	MM380 GT516 GE14 GW14110	Description Mast Guy Attachment Guy Thimbles Guy End 20 ft. of 1/4 in. Guy Wire	MM95	516		
/4 in. Guy Kit	1	MM380 GT516 GE14 GW14110 GC902	Description Mast Guy Attachment Guy Thimbles Guy End 20 ft. of 1/4 in. Guy Wire Guy Clamp	MM95	516		
/4 in. Guy Kit	1 2	MM380 GT516 GE14 GW14110 GC902 RB404	Description Mast Guy Attachment Guy Thimbles Guy End 20 ft. of 1/4 in. Guy Wire Guy Clamp Roof Bracket	MM95	516		
/4 in. Guy Kit MM914	1 2	MM380 GT516 GE14 GW14110 GC902	Description Mast Guy Attachment Guy Thimbles Guy End 20 ft. of 1/4 in. Guy Wire Guy Clamp	MM95	516		
/4 in. Guy Kit MM914	1 2	MM380 GT516 GE14 GW14110 GC902 RB404 T404-CM	Description Mast Guy Attachment Guy Thimbles Guy End 20 ft. of 1/4 in. Guy Wire Guy Clamp Roof Bracket Lag Screw	MM95	516		
/4 in. Guy Kit MM914	1 2	MM380 GT516 GE14 GW14110 GC902 RB404 T404-CM MM380	Description Mast Guy Attachment Guy Thimbles Guy End 20 ft. of 1/4 in. Guy Wire Guy Clamp Roof Bracket Lag Screw Mast Guy Attachment	MM95	516		
/4 in. Guy Kit MM914	1 2	MM380 GT516 GE14 GW14110 GC902 RB404 T404-CM MM380 GT516	Description Mast Guy Attachment Guy Thimbles Guy End 20 ft. of 1/4 in. Guy Wire Guy Clamp Roof Bracket Lag Screw Mast Guy Attachment Guy Thimble	MM95	516		
/4 in. Guy Kit MM914 5/16 in. Guy Kit	1 2	MM380 GT516 GE14 GW14110 GC902 RB404 T404-CM MM380 GT516 GE516	Description Mast Guy Attachment Guy Thimbles Guy End 20 ft. of 1/4 in. Guy Wire Guy Clamp Roof Bracket Lag Screw Wast Guy Attachment Guy Thimble Guy Clamp	MM95	516		
I/4 in. Guy Kit MM914	1 2	MM380 GT516 GE14 GW14110 GC902 RB404 T404-CM MM380 GT516 GE516 GE516 GW516110	Description Mast Guy Attachment Guy Thimbles Guy End 20 ft. of 1/4 in. Guy Wire Guy Clamp Roof Bracket Lag Screw Mast Guy Attachment Guy Clamp Roof Bracket Lag Screw Understand Guy Thimble Guy End 20 ft. of 5/16 in. Guy Wire	MM95	516		
1/4 in. Guy Kit MM914 5/16 in. Guy Kit	1 2 1	MM380 GT516 GE14 GW14110 GC902 RB404 T404-CM MM380 GT516 GE516 GW516110 GC902	Description Mast Guy Attachment Guy Thimbles Guy End 20 ft. of 1/4 in. Guy Wire Guy Clamp Roof Bracket Lag Screw Mast Guy Attachment Guy Thimble Guy Clamp Roof Bracket Lag Screw U Mast Guy Attachment Guy End 20 ft. of 5/16 in. Guy Wire Guy Clamp	MM95	516		
5/16 in. Guy Kit	1 2 1	MM380 GT516 GE14 GW14110 GC902 RB404 T404-CM MM380 GT516 GE516 GE516 GW516110	Description Mast Guy Attachment Guy Thimbles Guy End 20 ft. of 1/4 in. Guy Wire Guy Clamp Roof Bracket Lag Screw Mast Guy Attachment Guy Clamp Roof Bracket Lag Screw Understand Guy Thimble Guy End 20 ft. of 5/16 in. Guy Wire	MM95	516		

