









Selection and ordering data

Version	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Connection cables (essential accessory)						
Connection cable						
For connection of						
	Central units with expansion modules or interface module	Diagnostics modules with central unit or interface module				
3UF7932-0AA00-0	✓	✓	• Length 0.025 m (flat) ▶	3UF7930-0AA00-0	1	1 unit 42J
--	--	✓	• Length 0.1 m (flat) ▶	3UF7931-0AA00-0	1	1 unit 42J
--	--	✓	• Length 0.3 m (flat) ▶	3UF7935-0AA00-0	1	1 unit 42J
--	--	✓	• Length 0.5 m (flat) ▶	3UF7932-0AA00-0	1	1 unit 42J
--	--	✓	• Length 0.5 m (round) ▶	3UF7932-0BA00-0	1	1 unit 42J
--	--	✓	• Length 1.0 m (round) ▶	3UF7937-0BA00-0	1	1 unit 42J
--	--	✓	• Length 2.5 m (round) ▶	3UF7933-0BA00-0	1	1 unit 42J
PC cables and adapters						
RS 232 PC cables						
	For connecting to the serial interface of a PC/PG, for communication with 3RK3 through the system interface		▶	3UF7940-0AA00-0	1	1 unit 42J
3UF7940-0AA00-0						
USB PC cables						
	For connecting to the USB interface of a PC/PG, for communication with 3RK3 through the system interface, recommended for use in connection with 3RK3		▶	3UF7941-0AA00-0	1	1 unit 42J
3UF7941-0AA00-0						
USB/serial adapters						
	For connecting a RS 232 PC cable to the USB interface of a PC		B	3UF7946-0AA00-0	1	1 unit 42J
3UF7941-0AA00-0						
Interface covers						
Interface covers						
	For system interface		▶	3UF7950-0AA00-0	1	5 units 42J
3UF7950-0AA00-0						
Memory modules						
Memory modules						
	For backing up the complete parameterization of the 3RK3 Modular Safety System without a PC/PG through the system interface		A	3RK3931-0AA00	1	1 unit 42C
3RK3931-0AA00						
Door adapters						
Door adapters						
	For external connection of the system interface, e.g. outside a control cabinet		▶	3UF7920-0AA00-0	1	1 unit 42J
3UF7920-0AA00-0						
Push-in lugs						
Push-in lugs for screw fixing						
	e.g. on mounting plate, 2 units required per device Can be used for 3RK3		B	3RP1903	1	10 units 41H
3RP1903						
✓ Available						
-- Not available						

Note:

More accessories and components that can be combined with MSS see Chapter 2 "Industrial Communication".