

System proS

Pilot Device Kits for D.O.L. Starters



Customer or factory installed pilot device kits for D.O.L starters or enclosed contactors

Pilot Light	# of Devices	Description	Nameplate Language	Nameplate Text	Suffix for factory installation	Catalog Number
130V	1	Pilot Light	English	ON	G	PS-PL
130V	3	Push buttons + Pilot light	English	START / STOP / ON	B	PS-SSI
130V	2	2 Position Switch + Pilot Light	English	OFF-ON / ON	D	PS-SL2I
130V	2	2 Position Keyed Switch + Pilot light	English	OFF-ON / ON	XB	PS-SL2KI
130V	2	3 Position Switch + Pilot Light	English	HAND-OFF-AUTO / ON	F	PS-SL3I
130V	2	3 Position Keyed Switch + Pilot light	English	HAND-OFF-AUTO / ON	XD	PS-SL3KI
130V	1	Pilot Light	French	EN SERVICE	P	PS-PL-F
130V	3	Push buttons + Pilot light	French	MARCHE / ARRET / EN SERVICE	J	PS-SSI-F
130V	2	2 Position Switch + Pilot Light	French	HORS-EN / EN SERVICE	L	PS-SL2I-F
130V	2	2 Position Keyed Switch + Pilot light	French	HORS-EN / EN SERVICE	XK	PS-SL2KI-F
130V	2	3 Position Switch + Pilot Light	French	MAN-HORS-AUTO / ON	N	PS-SL3I-F
130V	2	3 Position Keyed Switch + Pilot light	French	MAN-HORS-AUTO / EN SERVICE	XM	PS-SL3KI-F
24V	1	Pilot Light	English	ON	G	PS-PLF
24V	3	Push buttons + Pilot light	English	START / STOP / ON	B	PS-SSIF
24V	2	2 Position Switch + Pilot Light	English	OFF-ON / ON	D	PS-SL2IF
24V	2	2 Position Keyed Switch + Pilot light	English	OFF-ON / ON	XB	PS-SL2KIF
24V	2	3 Position Switch + Pilot Light	English	HAND-OFF-AUTO / ON	F	PS-SL3IF
24V	2	3 Position Keyed Switch + Pilot light	English	HAND-OFF-AUTO / ON	XD	PS-SL3KIF
24V	1	Pilot Light	French	EN SERVICE	P	PS-PLF-F
24V	3	Push buttons + Pilot light	French	MARCHE / ARRET / EN SERVICE	J	PS-SSIF-F
24V	2	2 Position Switch + Pilot Light	French	HORS-EN / EN SERVICE	L	PS-SL2IF-F
24V	2	2 Position Keyed Switch + Pilot light	French	HORS-EN / EN SERVICE	XK	PS-SL2KIF-F
24V	2	3 Position Switch + Pilot Light	French	MAN-HORS-AUTO / ON	N	PS-SL3IF-F
24V	2	3 Position Keyed Switch + Pilot light	French	MAN-HORS-AUTO / EN SERVICE	XM	PS-SL3KIF-F
--	2	Push buttons	English	START / STOP	A	PS-SS
--	2	Push buttons	English	START / EMERGENCY STOP	Q	PS-SE
--	3	Push buttons	English	START / STOP / EMERGENCY STOP	YA	PS-SSE
--	1	2 Position Switch	English	OFF-ON	C	PS-SL2
--	1	2 Position Keyed Switch	English	OFF-ON	XA	PS-SL2K
--	1	3 Position Switch	English	HAND-OFF-AUTO	E	PS-SL3
--	1	3 Position Keyed Switch	English	HAND-OFF-AUTO	XC	PS-SL3K
--	2	Push buttons	French	MARCHE / ARRET	H	PS-SS-F
--	2	Push buttons	French	MARCHE / ARRET D'URGENCE	R	PS-SE-F
--	3	Push buttons	French	MARCHE / ARRET / ARRET D'URGENCE	YB	PS-SSE-F
--	1	2 Position Switch	French	HORS-EN	K	PS-SL2-F
--	1	3 Position Switch	French	MAN-HORS-AUTO	M	PS-SL3-F
--	1	2 Position Keyed Switch	French	HORS-EN	XJ	PS-SL2K-F
--	1	3 Position Keyed Switch	French	MAN-HORS-AUTO	XL	PS-SL3K-F