

## HINGED WALL MOUNT BRACKET

PART NUMBERS: WBH1, WBH2, WBH3, WBH4, WBH2E, WBH4E, WBH6E

## **CM23A INSTALLATION INSTRUCTIONS**


© Panduit Corp. 2002 Printed in U.S.A.

## TO MOUNT BRACKET TO WALL OR 19" RACK:

- 1. Determine desired wall or rack mounting location.
- 2. Insert appropriate hardware (screws not included) through keyways in rear of bracket and fasten securely to wall, or insert through round holes and fasten securely to rack..
- 3. Hinged bracket is removable so that equipment can hinge open on either side.

## TO INSTALL EQUIPMENT ON BRACKET:

- 1. Determine desired mounting location for equipment.
- 2. Align equipment on bracket.
- 3. Insert #12-24 screws (not included) into equipment and screw into mounting bracket holes on either side .
- 4. To access back of equipment, remove L-bracket screws.



NOTE: WBHE models are packaged without hinges or L-brackets installed. Mount hinges and L-brackets on the outside of the Main Bracket as shown, using the supplied #12-24 screws and pem nuts. Make certain the pem nuts are facing the back of the Main Bracket.

WORLDWIDE SUSIDIARIES AND SALES OFFICES



412 Rockwell Court Burr Ridge, Illinois 60521 Technical Support: 866-405-6654 Fax: 708-444-6993 E-mail: netconnsupport@panduit.com Web site: www.panduit.com/ncg