Push buttons at a glance

Contents

The inside story 1
Hot buttons 2
Non-illuminated push buttons 3
Illuminated push buttons 5
Non-illuminated selector switches 7
Illuminated selector switches 13
Pilot lights 17
Special forms 19
Technical data 21

The inside story on CR104P push buttons



CR104P push buttons are suitable for use in Types 1, 3, 3R, 4, 4X, 12 and 13 applications when mounted in enclosures rated for those same applications.

Snap-on caps come in eight different colors and in clear.

Octagonal mounting rings meet stringent automotive industry standards.

Nameplates are available in red or black, blank or with standard markings.

Rubber gasket helps seal push button against oil, water and dust.

Spacers are added or removed to accommodate different panel thicknesses.

Bellows-type rubber seal keeps out contaminants.

Color-coded plungers allow tell you quickly and accurately whether contact is normally open or closed. On standard single block, NO is green; NC is red. On double block, NO/NC is white.

Modular contact blocks can be easily added to meet circuitry requirements.

Clear contact block covers facilitate fast, precise contact inspection.

Contact block mounting via a single captive screw saves installation time and money.

Hot Buttons

Description			Catalog numbers				
			Assembled for maximum simplicity	Legend plate	Components for maximum flexibility		
					Operator	+	Contact block (or other component)
PUSH BUTTONS	START (Black)	1NO	CR104PBG10B1	CR104PXN1BP037	CR104PBG00B1 or CR104PBG00U1	+	CR104PXC1
	STOP (Red)	1NC	CR104PG01R1	CR104PXN1RP040	CR104PBG00R1 or CR104PBG00U1	+	CR104PXC01
Emergency stop (mushroom-head)	Push-pull	1NC	CR104PBM01R5C	CR104PXN2RP009	CR104PBM00R5C	+	CR104PXC01
Illuminated push-pull	120V transformer	1NO-1NC	CR104PBT11R5C2	—	CR104PBT11R5C		—
Illuminated, guarded	120V transformer	1NO-1NC	CR104PBT11G3S2	—	CR104PBT11A1S2	+	CR104PXL05R (lens) + CR104PXG04 (guard)
SELECTOR SWITCHES	OFF-ON (Black)	1NO-1NC	CR104PSG21B91	CR104PXN1BP057	CR104PSG21B	+	CR104PXC91
	HAND-OFF-AUTO (Black)	1NO-1NC	CR104PSG34B91	CR104PXN1BP070	CR104PSG34B	+	CR104PXC91
PILOT LIGHTS	Red (ON)	120V Full voltage	CR104PLG22R	CR104PXN1BP025	CR104PLG22A	+	CR104PXL01R
	Green (OFF)	120V Full voltage	CR104PLG22G	CR104PXN1BP024	CR104PLG22A	+	CR104PXL01G
	Red Push-To-Test (ON)	120V Transformer	CR104PLT32R	CR104PXN1BP025	CR104PLT32A	+	CR104PXL07R
	Green Push-To-Test (OFF)	120V Transformer	CR104PLT32G	CR104PXN1BP024	CR104PLT32A	+	CR104PXL07G

Alternate buttons for local market needs

PUSH BUTTONS							
Emergency stop (mushroom-head)	Basic	1NC	CR104PBM01R5	CR104PXN2RP009	CR104PBM00R5	+	CR104PXC01
	Push/turn-to-release	1NC	CR104PTR20A0R01	CR104PXN2RP009	CR104PTR20A0R	+	CR104PXC01
PILOT LIGHTS	Red (ON)	120V Transformer	CR104PLG32R	CR104PXN1BP025	CR104PLG32A	+	CR104PXL01R
	Green (OFF)	120V Transformer	CR104PLG32G	CR104PXN1BP024	CR104PLG32A	+	CR104PXL01G
	Red Push-To-Test (ON)	120V Full voltage	CR104PLT22R	CR104PXN1BP025	CR104PLT22A	+	CR104PXL07R
	Green Push-To-Test (OFF)	120V Full voltage	CR104PLT22G	CR104PXN1BP024	CR104PLT22A	+	CR104PXL07G