







Model Number

NCB5-18GM40-N0-5M

Features

- Comfort series
- 5 mm flush

Accessories

EXG-18

Quick mounting bracket with dead stop

BF 18

Mounting flange, 18 mm

Technical Data

General specifications Switching element function

Rated operating distance 5 mm s_n Installation NAMUR Output polarity Assured operating distance Actual operating distance 0 ... 4.05 mm 4.5 ... 5.5 mm typ. 5 mm Reduction factor r_{Al} Reduction factor r_{Cu} 0.3 Reduction factor r₃₀₄ 0.74

NAMUR, NC

Nominal ratings

Nominal voltage 8 V 0 ... 400 Hz Switching frequency Hysteresis 1 ... 15 typ. 5 % Reverse polarity protection reverse polarity protected yes

Short-circuit protection Current consumption

Measuring plate not detected Measuring plate detected Switching state indicator all direction LED, yellow

Functional safety related parameters

MTTF_d
Mission Time (T_M) 2040 a Diagnostic Coverage (DC) 0%

Ambient conditions

-25 ... 100 °C (-13 ... 212 °F) -40 ... 100 °C (-40 ... 212 °F) Ambient temperature Storage temperature

Mechanical specifications

cable PVC, 5 m Connection type Core cross-section 0.75 mm^2 Housing material Stainless steel 1.4305 / AISI 303

Sensing face PBT Degree of protection IP67 Cable

> 10 x cable diameter Bending radius

General information

Use in the hazardous area see instruction manuals 1G; 2G; 3G; 1D; 3D Category

Compliance with standards and directives

Standard conformity


EN 60947-5-6:2000 **NAMUR** IEC 60947-5-6:1999 EN 60947-5-2:2007 Standards IEC 60947-5-2:2007

Approvals and certificates


cULus Listed, General Purpose UL approval CSA approval cCSAus Listed, General Purpose

CCC approval CCC approval / marking not required for products rated ≤36 V

Dimensions



Electrical Connection



FPEPPERL+FUCHS

ATEX 1G

Instruction

Device category 1G EC-Type Examination Certificate CE marking

ATEX marking

Directive conformity Standards

Appropriate type

Effective internal capacitance Ci Effective internal inductance Li

General

Ambient temperature

Installation, commissioning

Maintenance

Special conditions

Protection from mechanical danger

Electrostatic charge

Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist PTB 00 ATEX 2048 X €0102

⟨ II 1G Ex ia IIC T6...T1 Ga

EN 60079-0:2012, EN 60079-11:2012, EN 60079-26:2007 Ignition protection "Intrinsic safety"
Use is restricted to the following stated conditions

NCB5-18GM...-N0...

 \leq 95 nF ; a cable length of 10 m is considered.

 \leq 100 μ H; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual.

The EC-Type Examination Certificate has to be observed. The special conditions

Directive 94/9/EG and hence also EC-Type Examination Certificates apply in general only to the use of electrical apparatus under atmospheric conditions. The use in ambient temperatures of > 60 $^{\circ}$ C was tested with regard to hot surfaces

by the mentioned certification authority.

If the equipment is not used under atmospheric conditions, a reduction of the permissible minimum ignition energies may have to be taken into consideration.

The temperature ranges, according to temperature class, are given in the EC-Type Examination Certificate. Note: Use the temperature table for category 1 $ext{!!!}$ The 20 $ext{\%}$ reduction in accordance with EN 1127-1:2007 has already been accounted for in the temperature table for category 1.

Laws and/or regulations and standards governing the use or intended usage goal

must be observed.

The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

The associated apparatus must satisfy the requirements of category ia

Due to the possible danger of ignition, which can arise due to faults and/or transient currents in the equipotential bonding system, galvanic isolation of the power supply and signal circuit is preferable. Associated apparatus without electrical isolation must only be used if the appropriate requirements of IEC 60079-14 are met.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.

Electrostatic charges on the metal housing components must be avoided. Dangerous electrostatic charges on the metal housing components can be avoided by incorporating these components in the equipotential bonding.

ATEX 2G

Instruction

Device category 2G

EC-Type Examination Certificate CE marking

ATEX marking Directive conformity Standards

Appropriate type

Effective internal capacitance Ci Effective internal inductance L

Ambient temperature

Installation, commissioning

Maintenance

Special conditions

Protection from mechanical danger

Electrostatic charge

Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist PTB 00 ATEX 2048 X €0102

⟨ II 1G Ex ia IIC T6...T1 Ga

94/9/EG

EN 60079-0:2012, EN 60079-11:2012 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions

NCB5-18GM...-N0...

 \leq 95 nF; a cable length of 10 m is considered.

 \leq 100 μ H; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to!

Directive 94/9/EG and hence also EC-Type Examination Certificates apply in general only to the use of electrical apparatus under atmospheric conditions

The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces

by the mentioned certification authority.

If the equipment is not used under atmospheric conditions, a reduction of the permissible minimum ignition energies may have to be taken into consideration.

The temperature ranges, according to temperature class, are given in the EC-Type Examination Certificate.

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

When used in the temperature range below -20 $^{\circ}\text{C}$ the sensor should be protected from knocks by the provision of an additional housing.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

ATEX 3G (nL)

Note

Instruction

Device category 3G (nL)

CE marking

ATEX marking

Directive conformity
Standard conformity

Effective internal capacitance $\,C_{i}$ Effective internal inductance $\,L_{i}$

General

Installation, commissioning

Maintenance

Special conditions

Maximum permissible ambient temperature T_{Umax} at Ui = 20 V

for Pi=34 mW, li=25 mA, T6
for Pi=34 mW, li=25 mA, T5
for Pi=34 mW, li=25 mA, T4-T1
for Pi=64 mW, li=25 mA, T6
for Pi=64 mW, li=25 mA, T5
for Pi=64 mW, li=25 mA, T4-T1
for Pi=169 mW, li=52 mA, T6
for Pi=169 mW, li=52 mA, T5
for Pi=169 mW, li=52 mA, T5
for Pi=169 mW, li=52 mA, T4-T1
for Pi=242 mW, li=76 mA, T6
for Pi=242 mW, li=76 mA, T5
for Pi=242 mW, li=76 mA, T5
for Pi=242 mW, li=76 mA, T4-T1

Protection from mechanical danger

Protection from UV light

Protection of the connection cable

Electrostatic charge

Connection parts

This instruction is only valid for products according to EN 60079-15:2005, valid until 01-May-2013

Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist

€0102

⟨ II 3G Ex nL IIC T6 X The Ex-significant identification is on the enclosed adhesive label

94/9/EG

EN 60079-15:2005 Ignition protection category "n" Use is restricted to the following stated conditions

 \leq 95 nF; a cable length of 10 m is considered.

 \leq 100 μH ; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction!

The special conditions must be observed!

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The sensor must only be operated with energy-limited circuits, which satisfy the requirements of IEC 60079-15. The explosion group depends on the connected and energy-limited supply circuit.

The adhesive label provided must be affixed in the immediate vicinity of the sensor! The surface to which the label is applied must be clean, flat and free from grease! The affixed adhesive label must be readable and durable, taking account of the possibility of chemical corrosion!

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

55 °C (131 °F)
55 °C (131 °F)
52 °C (125.6 °F)
52 °C (125.6 °F)
52 °C (125.6 °F)
44 °C (111.2 °F)
44 °C (111.2 °F)
44 °C (111.2 °F)

The sensor must not be exposed to **ANY FORM** of mechanical danger. When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.

The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor is used in internal areas.

The connection cable must be prevented from being subjected to tension and torsional loading.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

The connection parts are to be installed, such that a minimum protection class of IP20 is achieved, in accordance with IEC 60529.

ATEX 3G (ic)

Instruction

Device category 3G (ic)

Certificate of Compliance

CE marking

ATEX marking

Directive conformity

Standards

Effective internal capacitance Ci

Effective internal inductance L

General

Installation, commissioning

Maintenance

Special conditions

for Pi=34 mW li=25 mA T6 for Pi=34 mW, Ii=25 mA, T5 for Pi=34 mW, Ii=25 mA, T4-T1 for Pi=64 mW, Ii=25 mA, T6 for Pi=64 mW, Ii=25 mA, T5 for Pi=64 mW. Ii=25 mA. T4-T1 for Pi=169 mW, Ii=52 mA, T6 for Pi=169 mW, Ii=52 mA, T5 for Pi=169 mW, Ii=52 mA, T4-T1 for Pi=242 mW, Ii=76 mA, T6 for Pi=242 mW, Ii=76 mA, T5 for Pi=242 mW. Ii=76 mA. T4-T1 Protection from mechanical danger

Electrostatic charge

Connection parts

Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist PF 13 CERT 2895 X

(€

EN 60079-0:2012, EN 60079-11:2012 Ignition protection category "ic" Use is restricted to the following stated conditions

≤ 95 nF; a cable length of 10 m is considered.

 \leq 100 μH ; A cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction!

The special conditions must be observed!

Laws and/or regulations and standards governing the use or intended usage goal must be observed.

The sensor must only be operated with energy-limited circuits, which satisfy the requirements of IEC 60079-11.

The explosion group complies with the connected, supplying, power limiting circuit. The adhesive label provided must be affixed in the immediate vicinity of the sensor! The surface to which the label is applied must be clean, flat and free from grease! The affixed adhesive label must be readable and durable, taking account of the possibility of chemical corrosion!

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

55 °C (131 °F) 52 °C (125.6 °F) 52 °C (125.6 °F) 52 °C (125.6 °F) 44 °C (111.2 °F) 44 °C (111.2 °F) 44 °C (111.2 °F)

The sensor must not be mechanically damaged.

When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

The connection parts are to be installed, such that a minimum protection class of IP20 is achieved, in accordance with IEC 60529.

fa-info@sg.pepperl-fuchs.com

www.pepperl-fuchs.com

fa-info@us.pepperl-fuchs.com

ATEX 1D

Instruction

Device category 1D

EC-Type Examination Certificate CE marking

ATEX marking

Directive conformity Standards

Appropriate type

Effective internal capacitance Ci Effective internal inductance Li

General

Maximum housing surface temperature

Installation, commissioning

Maintenance

Special conditions

Electrostatic charge

Manual electrical apparatus for hazardous areas

for use in hazardous areas with combustible dust **ZELM 03 ATEX 0128 X** €0102

 $\mbox{\@black}\mbox{ II 1D Ex iaD 20 T 108 °C (226.4 °F)}$ The Ex-significant identification is on the enclosed adhesive label

IEC 61241-11:2002: draft; prEN61241-0:2002 type of protection intrinsic safety "iD

Use is restricted to the following stated conditions

NCB5-18GM...-N0...

≤ 95 nF; a cable length of 10 m is considered.

 \leq 100 μ H; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual.

The EC-Type Examination Certificate has to be observed.

The special conditions must be adhered to!

The maximum surface temperature of the housing is given in the EC-Type Examina-

Laws and/or regulations and standards governing the use or intended usage goal

must be observed.

The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

The associated apparatus must satisfy at least the requirements of category ia IIB or iaD. Because of the possibility of the danger of ignition, which can arise due to faults and/or transient currents in the equipotential bonding system, galvanic isolation in the power supply and signal circuits is preferable. Associated apparatus without electrical isolation must only be used if the appropriate requirements of IEC 60079-14 are met. The intrinsically safe circuit has to be protected against influences due to lightning.

The adhesive label provided must be affixed in the immediate vicinity of the sensor!

The surface to which the label is applied must be clean, flat and free from grease! The affixed adhesive label must be readable and durable, taking account of the possibility of chemical corrosion!

When used in the isolating wall between Zone 20 and Zone 21 or Zone 21 und Zone 22 the sensor must not be exposed to any mechanical danger and must be sealed in such a way, that the protective function of the isolating wall is not impaired. The applicable directives and standards must be observed.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

The connection cables are to be laid in accordance with EN 50281-1-2 and must not normally be subjected to chaffing during use.

ATEX 3D Note

This instruction is only valid for products according to EN 50281-1-1, valid until 30-September-2008

Note the ex-marking on the sensor or on the enclosed adhesive label

Instruction Manual electrical apparatus for hazardous areas

Device category 3D

for use in hazardous areas with non-conducting combustible dust

€0102 CE marking

ATEX marking (II 3D IP67 T 109 °C (228.2 °F) X

94/9/EG Directive conformity Standards EN 50281-1-1 Protection via housing

Use is restricted to the following stated conditions

General The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction! The special conditions must be adhered to!

Installation, commissioning Laws and/or regulations and standards governing the use or intended usage goal must be observed.

No changes can be made to apparatus, which are operated in hazardous areas.

Repairs to these apparatus are not possible.

Special conditions

Maintenance

A minimum series resistance RV is to be provided between the power supply voltage and the proximity switch in accordance Minimum series resistance Ry

with the following list. This can also be assured by using a switch amplifier. The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances are Maximum operating voltage U_{Bmax}

Maximum heating (Temperature rise) Values can be obtained from the following list, depending on the max. operating voltage Ub max and the minimum series resistance Rv.

9 K at U_{Bmax}=9 V, R_V=562 Ω

using an amplifier in accordance with 9 K EN 60947-5-6

Protection from mechanical danger The sensor must not be mechanically damaged.

Protection of the connection cable The connection cable must be prevented from being subjected to tension and torsional loading.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding. Electrostatic charge

8

ATEX 3D (tc)

Instruction

Device category 3D

Certificate of Compliance CE marking

ATEX marking

Directive conformity Standards

General

Installation, commissioning

Maintenance

Special conditions

Minimum series resistance R_V

Maximum operating voltage U_{Rmax}

Maximum permissible ambient temperature T_{Umax}

at U_{Bmax} =9 V, R_V =562 Ω

using an amplifier in accordance with EN 60947-5-6

Protection from mechanical danger

Protection from UV light

Protection of the connection cable

Electrostatic charge

Manual electrical apparatus for hazardous areas

for use in hazardous areas with combustible dust PF 15CERT3774 X

€0102

(x) II 3D Ex tc IIIC T80°C Dc The Ex-related marking can also be printed on the enclosed label.

94/9/FG

EN 60079-0:2012+A11:2013, EN 60079-31:2014

Protection by enclosure "tc" Some of the information in this instruction manual is more specific than the information provided in the datasheet

The corresponding datasheets, declarations of conformity, EC-type examination certificates. certifications, and control drawings, where applicable (see datasheets), form an integral part of this document. These documents can be found at www.pepperlfuchs.com. The maximum surface temperature of the device was determined without a layer of dust on the apparatus. Some of the information in this instruction manual is more specific than the information provided in the datasheet.

Laws and/or regulations and standards governing the use or intended usage goal must be observed. If the Ex-relevant identification is printed exclusively on the adhesive label provided, this label must be affixed in the immediate vicinity of the sensor! The background surface to which the adhesivelabel is to be applied must be clean and free from grease! The applied label must be durable and remain legible, with due consideration of the possibility of chemical corrosion!

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

A minimum series resistance RV is to be provided between the power supply voltage and the proximity switch in accordance with the following list. This can also be assured by using a switch amplifier.

The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances are not permitted.

Values can be obtained from the following list, depending on the max. operating voltage Ub max and the minimum series resistance Rv.

61 °C (141.8 °F)

61 °C (141.8 °F)

The sensor must not be exposed to ANY FORM of mechanical danger.

The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor is used in internal areas.

The connection cable must be prevented from being subjected to tension and torsional

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding. Do not attach the nameplate provided in areas where electrostatic charge can build up.